


WIRING DIAGRAM - 1

For use with:


VA140KP
VA140UP
VA140KH
VA140UH
VA140VS
CENTRIF 170DP
CENTRIF 250DP
CENTRIF 170HP
CENTRIF 250HP
VA150P
VA150A
VA150X
VA150H
VA100X/VA100WCX
(VA100LH/VA100XH)
SOLO P
SOLO DP
SOLO TM 2
SOLO HP2
SOLO PLUS P
SOLO PLUS TM
LOWATT U/KP
LOWATT U/KH

USING THE INTEGRAL PULLCORD SWITCH (WHERE APPLICABLE)



WIRING DIAGRAM - 3

- For use with:
- VA140KT
 - VA140UT
 - VA140KH
 - VA140KHT
 - CENTRIF 250DP
 - CENTRIF 170HP
 - CENTRIF 250HP
 - CENTRIF 170T
 - CENTRIF 250T
 - VA150T
 - VA150HT
 - VA150H
 - SILHOUETTE 100T
 - SILHOUETTE 100H
 - SILHOUETTE 100TM
 - SILHOUETTE 150XT
 - SILHOUETTE 150XH
 - VA100XT/VA100LT
 - VA100WCXT/VA100XHT
 - (VA100LH/VA100XH)
 - SOLO DP
 - SOLO T
 - SOLO HP2
 - SOLO HT
 - SOLO PLUS T
 - SOLO PLUS HT
 - LOWATT U/KT



Not on all models